




3/8" (10 mm) Dia. Orbit
For Aggressive Sanding



3/16" (5 mm) Dia. Orbit
For General Sanding



3/32" (2.5 mm) Dia. Orbit
For Ultra-Fine Sanding



For efficient random orbital sanding and uniform finish, move the tool in "north-to-south" pattern, then change to "east-to-west" pattern. Be sure to sand complete surface in each pattern.

Remember the rule of "start ON, stop OFF." Place the tool ON the work surface before starting it, and move running tool OFF the surface before stopping it. This will help to prevent unwanted swirl marks.

