

How to stain edges with padding finish

1. Dampen Pad with Lacover® padding finish.
2. Work powdered Blendal® Stain into pad.
3. Pad over defect.
4. This method is generally employed to shade in larger defect and is most successfully used on furniture arms, legs, edges, etc.
5. Alternatively, apply dry powder Blendal® Stain to defect and then spray over area with a clear aerosol Tone Finish® toner. Fold Trace Cloth twice. Hold tight over finger. Apply Lacover® padding finish and rub Blendal® Stain on top and stroke lightly back and forth over area requiring stain and finish. This method is for small areas where stain and finish is required, such as edges carvings, and etc.

How to apply a padding finish to an entire surface

Unlike Lacover® padding finish which is recommended for spot refinishing and staining, Rapid Pad® padding finish flows and spreads more freely. Rapid Pad® padding finish is a surface padding finish that does not penetrate or bite into the original finish. Steaking or marks caused by overlapping can be easily avoided with this padding finish. Rapid Pad® padding finish should not be used in conjunction with padding stains because of its nature to spread, making it difficult to localize the stain to the spot requiring repair.

Procedure:

Application of Rapid Pad® padding finish is similar to that of Lacover® padding finish. Extremely fine surface scratches can be rubbed out with Rubbing Compound or Poly Buf™ compound of proper grit. Use Flat Lube® paste flattener on oil - walnut finishes.