

How to apply Lacover® padding finish with a padding pad

Procedure:

- A.** Put Padding pad in palm of hand.
- B.** Pour approximately 1/4 ounce of Lacover® padding finish into the pad. **Fig. 1**
Precaution: Never soak or saturate pad with Lacover® padding finish.
The pad should never feel wet but should feel moist or cool to the touch.
- C.** Disperse Lacover® padding finish throughout the pad by tapping pad into the open palm of the hand. **Fig. 2**
This will avoid a wet spot in the pad and will help produce an even flow during application.
- D.** Lacover® padding finish is never wiped on a surface in the same manner as standard furniture polishes. Imagine the swinging motion of the pendulum in a grandfather clock. **Fig. 3**
Lacover® padding finish should be applied in the same manner.
Do not bend the wrist or stop the swaying of the pad while on the surface.
Wherever possible, pad with the grain of the wood. **Fig. 4**
Avoid padding cross grain on any furniture surface.
- E.** Continue padding until surface or defective spot has been built up or refinished with Lacover® padding finish. Bare spots, packing marks, and surface scratches can be repaired with above method.
For an entire surface, we recommend Rapid Pad® padding finish or Lac French® padding finish.

Fig. 1



Fig. 2



Fig. 3



Fig. 4

