



Install #8 x 1" wood screw/Pozi drive

Note: Pre-drill holes with $\emptyset 2 \text{ mm}$ drill bit.

