

How to apply stain and finish in one operation

- A.** Disperse Lacover® padding finish throughout the pad by tapping pad into the open palm of the hand. This will avoid a wet spot in the pad and will help produce an even flow during application.
- B.** Before padding over the bare spot, select Blendal® powder stain colour that matches the shade of the surrounding finish. Apply Blendal® powder stain to index finger of the other hand. **Fig. 1**
- C.** Using a light stroke, pad several times over bare spot with Lacover® padding finish. **Fig. 2**
- D.** As soon as the last stroke is completed, immediately apply the stain with your fingertip to the unstained or damaged spot, rubbing lightly with the grain. **Fig. 3**
- E.** Once the stain has been applied, continue finishing operation by padding a light coat of Lacover® padding finish over re-stained spot. Use as light a stroke as possible following stain application. If stain "shifts" or does not "hold" in the repaired area, the pad is too wet with Lacover® padding finish or you are using too much pressure.
- F.** If stain is light in colour, repeat this operation until desired shade is attained. In many cases you will have to use 2 to 4 different shades of Blendal® powder stain to accomplish a perfect match. For example, start with a shade or two lighter than original finish and apply a darker shade over a light shade. This procedure will produce a better match. If the results are unsatisfactory, the repaired area can be washed off with Lacosolvent™ reducer and the entire procedure repeated without fear of damage to the surrounding area. **Fig. 4**

Spray a protective coat of Tone Finish® laquer of the proper sheen or pad with Lacover® padding finish.

Fig. 1



Fig. 2



Fig. 3



Fig. 4

