



USER GUIDE

READ BEFORE USE

For more details and video demonstrations,
Visit youtube.jayclamp.ca

WARNING

You assume the responsibility of any damage, loss or injury resulting from improper use of the product or incapacity to use the product properly. L'Ébéniste JL inc. cannot be held accountable in any of these cases.

Use proper safety equipment when using this product or any other tool that could harm yourself, others or the surroundings.

Instructions

1. Find the largest gap between the wall and the cabinet.
2. Cut a piece that will serve as the spacer/crown/toe kick. It's width must be the same as the measure taken at step 1. It's length must correspond to the space that needs to be filled in, while still having extra material at each end to be able to trace more precise cut lines.
3. Clamp three *JayClamp* to the edge of the cabinet with the red lever. Adjust clamping space if necessary.
4. Clamp the piece cut at step 2 to the *JayClamp* with the blue lever while making sure that it is parallel to the side of the cabinet.
5. With a block the same width as the cabinet's thickness, trace the wall's outline on the clamped piece. Then, remove the piece from the *JayClamp* using the blue lever.
6. With a saw, cut the spacer/crown/toe kick using the previously traced cut line.
7. Remove the *JayClamp* from the cabinet using the red lever.
8. Attach the spacer/crown/toe kick between the cabinet and the wall. Positioning blocks may be necessary.