## **Important Notice regarding handle position**

The pull handle mounted on the SLUN door must be posiitioned above the bottom pivot of the mounting plate on the door. See illustration below.

The door may not open, or may experience difficulty opening the door if the handle position is below this point.

Handle must be mounted above this point

3