

# Panther

## PRODUCT INFORMATION



### CORROSION CONTROL

P100H

P200C

### GLUE

P100G

P100G - Water Base

### ZINC

P200Z

### AIR CAP AND FLUID NOZZLE CHART

PANTHER model no.	AIR CAP	AIR CAP RING	FAN CONTROL	FLUID NOZZLE TIP	NEEDLE
P100H	21-1095T	21-1001	60-1502	31-0214 1.4mm	40-1100
				31-0215 1.5mm	
				31-0216 1.6mm	
				31-0217 1.7mm	
P100G	21-2266T	INCLUDED	60-1500	31-0618 1.8mm	40-1115
P200C	22-2064T 22-2062T	INCLUDED	60-1500	32-0618 1.8mm	40-1218
				32-0622 2.2mm	40-1222
				32-0628 2.8mm	40-1228
P200Z	22-2064T 22-2062T	INCLUDED	60-1500	32-2118Z 1.8mm	40-1218
				32-2122Z 2.2mm	40-1222
				32-2128 Z 2.8mm	40-1228

**C.A. Technologies**

PO BOX 17820 Boulder, Colorado 80301

[www.SprayCAT.com](http://www.SprayCAT.com)

<i>Panther</i> Model no.	ITEM 4	ITEM 5	ITEM 6	ITEM 7	ITEM 24	REPAIR KIT
<b>P100H</b>	31-1201	NOT USED	60-L11H	60-12H	60-1400*	10-110
<b>P100G</b>	31-2201	61-1005*	60-L11C	60-12C	60-1400*	10-110
<b>P200</b>	32-2202	998-8020*	60-L21C	60-22	60-1400*	10-110
<b>P200Z</b>	32-2201	998-8020*	60-L21C	60-22	60-1402**	10-108

ITEM NUMBER	PART NUMBER	DESCRIPTION	ITEM NUMBER	PART NUMBER	DESCRIPTION
1	See AIR CAP CHART	Air Cap Ring	19	See KIT NO. 10-108 & 10-110	Seal
2	See AIR CAP CHART	Air Cap	20	60-1520	Air Valve Assembly
3	See AIR CAP CHART	Fluid Nozzle Tip	21	60-302**	Air Valve Poppet
4	See <i>Panther</i> Model no.	Fluid Nozzle Body	22	See KIT NO. 10-108 & 10-110	Seal
5	See <i>Panther</i> Model no.	Gasket*	23	See KIT NO. 10-108 & 10-110	Air Valve Spring
6	See <i>Panther</i> Model no.	Nozzle Carrier	24	See <i>Panther</i> Model no.	Needle Seal Cartridge
7	See <i>Panther</i> Model no.	Air Cap Adapter	25	60-2101	Trigger
8	See KIT NO. 10-108 & 10-110	O-Ring	26	60-1510	Air Control
10	60-128	Locknut	26A	60-122	Plug (optional)
11	60-126	Fluid Inlet Fitting	27	60-104	Air Inlet Fitting
12	60-1116	<i>Panther</i> Gun body HVLP	28	60-1033	Trigger Pivot Set
	60-1125	<i>Panther</i> Gun body CONV.	29	98-109	Allen Plug
13	See Air Cap Chart	Fan Control Assembly	30	60-124	Fluid Inlet Seal
14	See Air Cap Chart	Fluid Needle	31	21-1592	Housing
15	60-202	Fluid Control Knob	32	21-1591	Swirl Insert
16	See KIT NO. 10-108 & 10-110	Spring Seat	33	31-1593-18	Nozzle
17	See KIT NO. 10-108 & 10-110	Needle Return Spring	34	40-1515	Needle
18	60-201	Rear Bushing			

\*Included in Kit # 10-108 & 10-110

\*\* Included with air valve assembly 60-1520

NOTE:

Items 31, 32 and 33 replace Items 1, 2 and 3 for the model P100G 1.8 x 1590 water base set-up

