

# Mohawk Fill One Machine Directions



For best results, the air compressor must apply 130 PSI of continuous pressure.

1. Choose the proper Fill-One pre-charged aerosol for your product by using the Mohawk Fill-One Product Selection Guide.
2. Remove the clear plastic cap and detach the clear plastic plunger attachment from the top of the cap and slide open the Fill One door, then firmly press the plunger attachment onto the plunger.
3. Remove spray head from the top of the fill can. Press the metal reservoir cup onto the top of the can. Slide the cap into the metal reservoir cup, pressing down so that it mates with the bottom of the cup.
4. Pour filtered paint to the reservoir cup, leaving a 1/4 inch from the top unfilled. (Overfilling will cause paint to spill out during the filling process.)
5. Place the reservoir and can into the filling machine by sliding the brim of the reservoir cup into the reservoir slot.
6. Rotate the black base counterclockwise to snug the connection between the can and cup. Do not over tighten base.
7. Close the door for 5-10 seconds. This will inject approximately 3 ounces of product into the can.
8. Open fill machine door. Turn the black base clockwise to loosen can and reservoir before removing them from the machine.
9. Separate metal reservoir cup from the can. Separate the plastic cap from the reservoir by hand or by pressing the cup down on a work surface, which will release the cap.
10. Insert spray head using a slight twisting motion with the spray nozzle pointing away from you and place the cap back on the can.
11. Shake can vigorously for 30 seconds to mix the contents.

To fill more cans with the same paint, repeat steps 1 thru 11.

Disconnect compressed air hose from compressor when not in use.

*Note: Since this aerosol can is incomplete without the addition of product, the custom packer assumes all responsibility for completing the filling operation as well as the performance of the finished product (including long term can stability).*

