






## MCLIN – Linear Range

Break Line



Break Line



MCLIN-Cap

MCLIN-Corner

MCLIN-Join

The Cap and the Join have break lines at the base of the fir tree. This enables sections of the fir tree to be cut then by bending back and forth, broken off.