


To raise the keyboard and monitor, pull the actuator handle (located under the work surface) upwards to release the lock. If additional force is required, apply a slight upward force to the opposite corner of the work surface or keyboard tray.

To lower the keyboard and monitor, pull the actuator handle (located under the work surface) upwards to release the lock. Provide the appropriate downward force on the work surface using the palms of your hands.

If you have difficulty lowering (i.e. it feels like the unit is stuck) provide additional downward force by gripping the actuator and apply additional downward force to the horizontal portion behind the column.



Sit2Stand Dual Monitor



Keyboard Tray Spacer



Actuator Handle



Plastic Cap




Small Cable Management Clip х3



Large Cable Management Clip x2

M5x12mm x 2 M5x25mm x 4 M5x35mm x 4



Crossbar

