flexxi

KESSEBÖHMER



A
472

1

2

A = min 472 mm
B = min 472 mm
C = min 130 mm



flexxi
KESSEBÖHMER

3



4



5



6

Press until it stops!



flexxi
KESSEBÖHMER

7



8

Installation only possible in the drawer!

9 B = min 472 → 11



10 B = min 520 → 11



flexxi
KESSEBÖHMER

11



12



13



14



flexxi
KESSEBÖHMER

15

Before removing from the drawer the product **dismantle** as described here!

1



2



flexxi
KESSEBÖHMER

Before removing from the drawer the product **dismantle** as described here!

3



4



flexxi

KESSEBÖHMER