

GEMSTONE, a modern solid surfacing material manufactured by Gemstone provides a choice of solid and patterned sinks and bowls to give a rich luxurious feeling to kitchens, wet bars, vanity tops, and many other applications. GEMSTONE solid surface sinks and bowls are manufactured with the color and pattern running throughout its thickness. This feature allows you to repair minor damages to maintain a like new appearance indefinitely.

While GEMSTONE Solid Surface is extremely tough and durable, like any fine material it can be damaged if abused or mistreated. Reviewing these care and cleaning instructions can assist you in understanding how easy it is to care for GEMSTONE Solid Surface products and how you can prevent more severe damage that may require professional repairs.

Normal Cleaning: GEMSTONE Solid Surface sinks and bowls are non-porous so they can be easily wiped clean with a damp cloth or sponge and mild detergents, such as 409® or Fantastic®, or general purpose cleaners. If you have a factory matte finish, abrasive cleaners may also be used. Periodically, it may also be helpful to go over the entire surface with an abrasive cleaner such as Bar Keepers Friend® or a wet blue Scotch Brite®* pad to maintain a uniform appearance. For tougher stains, a green Scotch Brite pad can be used.

Spills and Stains: While most everyday spills can be removed with the cleaning techniques mentioned, some troublesome spills and stains such as food/hair dye, tea and fruit drinks may require more aggressive cleaning. These items can be removed with a solution of 50/50 bleach and water allowed to sit for 15 minutes, drained, and flushed with water. Follow with a general cleaner and flush with water. On factory matte finish, if you prefer, you can scrub with an abrasive cleanser.

Some Simple Precautions: **DO NOT** place hot pans directly from the burner or the oven into the GEMSTONE Solid Surface sink or bowl. Even though GEMSTONE Solid Surface can withstand sustained temperatures up to 225°F., prolonged or extreme heat could cause yellowing and/or cracking. ***To prevent cracking due to extreme temperature differences, frozen foods should be placed on a mat or rack and not directly on the bottom of the sink to thaw.***

DO NOT use your sink for cutting or chopping items. Although minor cuts and scratches can be repaired, deep cuts will require the services of a professional, which is an extra expense.

DO NOT expose to extreme temperature fluctuations. ***Boiling water should be drained into the sink with lukewarm water running.*** Rapid changes in water temperature may cause cracking, this includes thawing frozen items.

Strong acids such as those found in drain cleaners, toilet bowl and oven cleaners should be used cautiously around GEMSTONE Solid Surfaces. If these items are accidentally spilled, wipe them up at once, flush with clear lukewarm water and wipe with a clean sponge.

Repairing Scratches: GEMSTONE solid surface sinks and bowls are usually supplied with a matte finish (unless specified otherwise) which is equivalent to sanding with 320 grit sandpaper or buffing with a wet #7448 Scotch Brite®* pad. For removing superficial scratches use a wet Scotch Brite®* scouring pad, available in most supermarkets, until the scratches are removed. Clean thoroughly with soap and water. Note: Deep scratches can be removed by first carefully sanding lightly with 120 grit sandpaper followed by 220- 320 grit sandpaper. Then use a wet #7448 Scotch Brite®* pad to restore the finish. (available from industrial supply houses) Gloss Finish (not recommended) For any damage, contact your fabricator/installer to repair.

* Registered trademark of 3M Corp.