

A Great Finish is Only the Beginning

Plasticolor[®] 900 White Post-Cat Pigmented TC 117-10XX

Product Code:

117-1020 117-1035 117-1050 117-1090

Low Gloss Satin Gloss Semi-Gloss Full Gloss
 VISCOSITY:
 Z #4/3

 FLASH POINT:
 63°F (*

 DENSITY (lb/gal):
 9.90

 SOLID (% by weight):
 65%

 SOLID (% by volume):
 51%

 SHELF LIFE (months):
 12

Z #4/30" at 77°F 63°F (17.2°C) 9.90 65% 51%

Product Description: Plasticolor[®] 900 White is an acid curing, light stable, fast drying Reactive Amino Coating (RAC) with good building properties. This is a fast building product due to its high solid content (51% volume). Plasticolor[®] 900 White gives a smooth, knock-proof and hardwearing surface resisting influence from alcohol, water, etc. Plasticolor[®] 900 White has very good light stability based on the type of resin used.

Special Recognition: When applied as specified, will meet required performance for the ANSI/KCMA A161.1 1990 9.0 Finish Test. Recommended: Architectural Woodwork Institute (AWI) O.P.4.

Uses: Plasticolor is used as the final coat over wood, plywood, chipboard, etc., meant for interior use. This product is recommended for kitchen cabinets, high build office or residential furniture as well as many other interior wood applications where high build and durability are required.

Environmental Data (as supplied):

VOC less exempt lb/gal:	<3.50
VOC lb/gal:	<3.50
VOC less exempt g/l:	<420
VOC g/l:	<420
VOC lb/lb Solid:	<0.55
VHAPs lb/lb Solid:	<0.30

See individual compliance sheets for specific data

Application Data:	SUGGESTED USES:	Wood Finish
	MIXING RATIO:	10 parts 117-10XX to 1 part 873-0870
	POT LIFE:	12 hours
	APPLICATION VISCOSITY:	Z #2/22 – 25"
	REDUCER:	803-1325
	RETARDER:	800-5328
	CLEAN-UP SOLVENT:	803-1298
	RECOMMENDED WET FILM:	5 mils
	COVERAGE:	866 sq. ft/gal at 1 mil dry and at 100% transfer efficiency.
		Coverage will vary depending on method of application or coating thickness.



Directions for Use

Surface Preparation: Primer should be sanded using 240 and 320 grit stearated paper. Suitable primers are Plastiprimer 900 MDF (522-1410) or Plastiprimer White (522-1420) for solid woods like Maple and Oak. Primers should be topcoated within eight hours of sanding. Care should be taken during sanding to avoid sanding through the primer.

General information: Catalyze and reduce the material as recommended. Plasticolor[®] 900 White is applied in one or two coats and can be used both as a primer and enamel on all kinds of wood meant for interior use. A premium system is however, obtained through priming with Plastiprimer 900 MDF (522-1410)

A thorough sanding between the coats is essential to the adhesion. The second and subsequent coats must be applied the same day as the previous coat is sanded. Plasticolor[®] 900 White cannot be used on metal, old oil or cellulose lacquers.

Total recommended film build of Plastiprimer 900 MDF (522-1410) and Plasticolor® 900 White (117-10XX) is not to exceed 6 mils dry. Over the primer, the topcoat should not exceed 4 mils dry.

To ensure proper sheen, the catalyzed material should be agitated at all times. Plasticolor[®] 900 White must be thoroughly stirred, while adding catalyst and thinner in the recommended mixing ratio. Contact with metal surfaces should be avoided once the Plasticolor[®] 900 White has been catalyzed.

Plasticolor[®] 900 White must not be polluted with oil, varnish or the like and must not be sanded with steel wool between coats. Plasticolor[®] 90 White must not be used and dried at temperatures below 65°F (18°C) or relative humidity above 65%. During the curing process, the coating must not be exposed to ammonia vapors. Ammonia cleaners should not be used for cleaning the finished surface. This may accelerate discoloration.

THE CUSTOMER IS RESPONSIBLE FOR FOLLOWING THE RECOMMENDED APPLICATION PROCEDURES. FAILURE TO ADHERE TO THE RECOMMENDATIONS GIVEN INTHIS DATA SHEET WILL LIKELY RESULT IN UNSATISFACTORY FILM APPEARANCE OR FILM FAILURE. THE COMPLETE COATING SYSTEM SHOULD BE CHECKED FOR REQUIRED PROPERTIES PRIOR TO THE START-UP OF PRODUCTION.

Drying Times:

Tack Free Time: Dry to Sand: Dry to Stack: At 68°F 15 – 20 mins. 3 hours Overnight At 122°F Flash off before entering oven 1 hour 3 hours

Note: Dry times are greatly affected by film build, porosity of substrate, air movement as well as heat and humidity. Temperatures are based on actual board temperature. This may vary depending on length of time for boards to reach these temperatures. Minimum curing temperatures of 64°F (18°C) must be maintained throughout the curing cycle to achieve the film integrity as stated in product features.

These products are designed for industrial use only. AkzoNobel views safety as a top priority. Please refer to Material Safety Data Sheet for information on the safe use of this product.

Values shown are calculated estimates and should not be construed as product specifications. We cannot anticipate all conditions under which this information and our products or the products of other manufacturers in combination with our products may be used. We accept no responsibility for results obtained by the application of this information or the safety and suitability of each such product or product combination for their own purposes. Unless otherwise agreed in writing, we sell the products without warranty, and users assume all responsibility for loss or damage arising from the use of our products whether used alone or a combination with other products. Use of unapproved or reclaimed solvent blends may reduce film properties and is not recommended.

Akzo Nobel Coatings, Inc 1431 Progress Ave High Point, NC 27261 336-841-5111